



Assembly Instructions

Mission Bench



Tools Needed: #2 square bit screw driver or power driver
No drilling is required. All the necessary holes are predrilled.

[View this product online at Premium Poly Patios](#)

Parts



Step 2 — Attach leg brace

8 - 2" screws, leg brace



Match the numbers on the leg brace to the numbers on the leg assemblies and attach with the 2" screws.

Step 1 — Attach leg assemblies

12 - 2½" screws, 2 leg assemblies



First, cover a table with a soft, clean blanket, and place the seat face-down. Next, match the numbers on the legs to the numbers on the bench-seat assembly and attach using six 2½" screws per leg assembly.

Congratulations!
Your **Mission Bench**
is ready to enjoy!

