



Assembly Instructions

TXLC Leg Kit



TXRCT236 TXRCT248
Cape Cod Round Cape Cod Round
36" Conversation 48" Conversation
Table Table



TXNCCT37 TXNCCT44
Yach Club 37" Yach Club 44"
Conversation Table Conversation Table

20-Year Warranty

Cleaning Tips

Keep your Trex Outdoor Furniture™ looking brand new:

For a quick clean:

Simply wipe down with soap and water.


For a deeper clean:

You'll need:


- » 1/3 bleach and 2/3 water solution
- » clean cloth
- » soft bristle brush

Wipe on solution with your cloth and let it sit on the lumber for a few minutes (this will not affect the color). Then, loosen any dirt and debris that may catch in surface grooves with a soft bristle brush; hose down to rinse.

TOOLS




4mm T-handle
hex key (included)





3/8" wrench
(not included)


PARTS



Separate box




3" Screw – H.27X3



2.5" Screw – HHW14X2.5

1


Do not over-tighten




TXFDT37 shown for parts and assembly

2


Do not over-tighten



3




4




Remove protective plastic
film from the logo medallion.

Removable table
plug included



TXNCCT37, TXNCCT44



TXRCT236, TXRCT248