




## Assembly Instructions



### 20-Year Warranty

### Cleaning Tips

Keep your Trex Outdoor Furniture™ looking brand new:

#### For a quick clean:

Simply wipe down with soap and water.

#### For a deeper clean:



You'll need:

- » 1/3 bleach and 2/3 water solution
- » clean cloth
- » soft bristle brush

Wipe on solution with your cloth and let it sit on the lumber for a few minutes (this will not affect the color). Then, loosen any dirt and debris that may catch in surface grooves with a soft bristle brush; hose down to rinse.


## Folding Ottoman

PARTS





## Assembly Instructions



**TXA53**  
Cape Cod  
Folding Adirondack

### 20-Year Warranty

### Cleaning Tips

Keep your Trex Outdoor Furniture™ looking brand new:

#### For a quick clean:

Simply wipe down with soap and water.


#### For a deeper clean:

You'll need:


- » 1/3 bleach and 2/3 water solution
- » clean cloth
- » soft bristle brush

Wipe on solution with your cloth and let it sit on the lumber for a few minutes (this will not affect the color). Then, loosen any dirt and debris that may catch in surface grooves with a soft bristle brush; hose down to rinse.

TOOLS



4mm T-handle  
hex key (included)



7/16" wrench  
(not included)


PARTS

**A** x2



1.875" Bolt — H.25-20X1.875

**B** x2




Nut




Washer

1



2




Nut



Washer

3



NOTE: Pins can be removed for folding