



20-year warranty

Great news! Your POLYWOOD warranty is already activated, no need to send anything in. Located on the bottom of each item is a sticker with a serial number. Please keep this number for your records.

View our full warranty:



If you have questions or concerns regarding assembly instructions or missing parts, please contact us at



Cleaning tips

For a Quick Clean:

Simply wipe down with soap and water.

For a Deep Clean:

Wipe on $\frac{1}{3}$ bleach and $\frac{2}{3}$ water solution with a clean cloth and let it sit on the lumber for a few minutes (this will not affect the color). Then, loosen any dirt and debris that may catch in surface grooves with a soft bristle brush; hose down to rinse.

For a High-Power Clean:

Use a pressure power washer (not exceeding 1,500 psi) to spray off dirt and debris. Apply a $\frac{1}{3}$ bleach and $\frac{2}{3}$ water solution and scrub with a soft bristle brush. Hose down to rinse.

POLYWOOD

Assembly Instructions



FDT37
Farmhouse 37\"/>



RT236
36\"/>




RT248
48\"/>




NCT37
Nautical 37\"/>

NCT44
Nautical 44\"/>

TOOLS




4mm T-handle
hex key (included)




3/8" wrench
(not included)


PARTS



Separate box




A x 8




3" Screw — H.27X3

B x 8




2.5" Screw — HHW14X2.5

1




Do not over-tighten




FDT37 shown for parts and assembly

2




Do not over-tighten




3

A x 4



4

A x 4



NCT37, NCT44



RT236, RT248



FDT37

POLYWOOD

Assembly Instructions



20-year warranty

View our full warranty:



If you have questions or concerns regarding assembly instructions or missing parts, please contact us at



Cleaning tips

For a Quick Clean:


Simply wipe down with soap and water.

For a Deep Clean:

Wipe on $\frac{1}{3}$ bleach and $\frac{2}{3}$ water solution with a clean cloth and let it sit on the lumber for a few minutes (this will not affect the color). Then, loosen any dirt and debris that may catch in surface grooves with a soft bristle brush; hose down to rinse.


For a High-Power Clean:

Use a pressure power washer (not exceeding 1,500 psi) to spray off dirt and debris. Apply a $\frac{1}{3}$ bleach and $\frac{2}{3}$ water solution and scrub with a soft-bristle brush. Hose down to rinse.



9010 Coastal Dining Chair

TOOLS




4mm T-handle
hex key (included)




4mm hex key
(included)

PARTS




A x 8




2.5" Screw — H.27X2.5

B x 4




3" Screw — H.27X3

1




Do not tighten screws until last step


2



3



4



Tighten all screws.

