



20-Year Warranty

Great news! Your POLYWOOD warranty is already activated, no need to send anything in. Located on the bottom of each item is a sticker with a serial number. **Please keep this number for your records.**

View our full warranty:



Cleaning Tips

For a Quick Clean:

Simply wipe down with soap and water.

For a Deep Clean:


Wipe on $\frac{1}{3}$ bleach and $\frac{2}{3}$ water solution with a clean cloth and let it sit on the lumber for a few minutes (this will not affect the color). Then, loosen any dirt and debris that may catch in surface grooves with a soft bristle brush; hose down to rinse.

For a High-Power Clean:

Use a pressure power washer (not exceeding 1,500 psi) to spray off dirt and debris. Apply a $\frac{1}{3}$ bleach and $\frac{2}{3}$ water solution and scrub with a soft bristle brush. Hose down to rinse.


POLYWOOD®

Assembly Instructions







1910 Signature Dining Chair

TOOLS




4mm T-handle
hex key (included)

PARTS




1




Do not tighten screws until last step.


2



3




4



Tighten all screws



Remove protective plastic
film from the logo medallion.





20-Year Warranty

Great news! Your POLYWOOD warranty is already activated, no need to send anything in. Located on the bottom of each item is a sticker with a serial number. **Please keep this number for your records.**

View our full warranty:



Cleaning Tips

For a Quick Clean:

Simply wipe down with soap and water.

For a Deep Clean:

Wipe on $\frac{1}{3}$ bleach and $\frac{2}{3}$ water solution with a clean cloth and let it sit on the lumber for a few minutes (this will not affect the color). Then, loosen any dirt and debris that may catch in surface grooves with a soft bristle brush; hose down to rinse.

For a High-Power Clean:

Use a pressure power washer (not exceeding 1,500 psi) to spray off dirt and debris. Apply a $\frac{1}{3}$ bleach and $\frac{2}{3}$ water solution and scrub with a soft bristle brush. Hose down to rinse.

POLYWOOD®

Assembly Instructions

PWLD Leg Kit



FDT37 Farmhouse 37" Dining Table



RT236 36" Round Farmhouse Dining Table


RT248 48" Round Farmhouse Dining Table




NCT37 Nautical 37" Dining Table

NCT44 Nautical 44" Dining Table

TOOLS



4mm T-handle
hex key (included)





3/8" wrench
(not included)


PARTS



Separate box




3" Screw — H.27X3




2.5" Screw — HHW14X2.5

1




Do not over-tighten




FDT37 shown for parts and assembly


2



Do not over-tighten




3




4


A x 4




Remove protective plastic
film from the logo medallion.



NCT37, NCT44



RT236, RT248



FDT37