



20-year warranty

View our full warranty:



If you have questions or concerns regarding assembly instructions or missing parts, please contact us at



Cleaning tips

For a Quick Clean:

Simply wipe down with soap and water.

For a Deep Clean:

Wipe on $\frac{1}{3}$ bleach and $\frac{2}{3}$ water solution with a clean cloth and let it sit on the lumber for a few minutes (this will not affect the color). Then, loosen any dirt and debris that may catch in surface grooves with a soft bristle brush; hose down to rinse.

For a High-Power Clean:

Use a pressure power washer (not exceeding 1,500 psi) to spray off dirt and debris. Apply a $\frac{1}{3}$ bleach and $\frac{2}{3}$ water solution and scrub with a soft-bristle brush. Hose down to rinse.

POLYWOOD

Assembly Instructions




**L1D81, L1R81,
L1B81**
**For Use With Small Plank
Table-PL81**

TOOLS




3/8" wrench
(not included)




4mm T-handle
hex key (included)

PARTS




A x 8



2.5" Screw — HHW14X2.5


B x 4




3" Screw — H.27X3

1


Align each screw with a
pilot hole and partially
thread by hand before
fully tightening




If legs have
relaxed during
transit, they
may be guided
into pilot hole
alignment



2



Removable
table plug



POLYWOOD

Assembly Instructions



20-year warranty

View our full warranty:



If you have questions or concerns regarding assembly instructions or missing parts, please contact us at



Cleaning tips

For a Quick Clean:


Simply wipe down with soap and water.

For a Deep Clean:

Wipe on $\frac{1}{3}$ bleach and $\frac{2}{3}$ water solution with a clean cloth and let it sit on the lumber for a few minutes (this will not affect the color). Then, loosen any dirt and debris that may catch in surface grooves with a soft bristle brush; hose down to rinse.


For a High-Power Clean:

Use a pressure power washer (not exceeding 1,500 psi) to spray off dirt and debris. Apply a $\frac{1}{3}$ bleach and $\frac{2}{3}$ water solution and scrub with a soft-bristle brush. Hose down to rinse.



QLD200, QLD202 Quattro Adirondack Chair

TOOLS




4mm T-handle
hex key (included)



4mm hex key
(included)

PARTS



A


x4



2.5" Screw — H.27X2.5


B

x2




3" Screw — H.27X3


1





2




3



4



QLD200



QLD202